


# HYBRID KEG INSTRUCTIONS


# KEG OUTLET

## OPENING

1. Depressurize the container by means of using the pressure relief valve.



2. Lift the lid lever to a vertical position.



3. Remove the lid by turning it to a 30 degree angle and moving it downwards by introducing the side of the lid without the pressure relief valve.



## CLOSING


1. Place the lid at a 30 degree angle respect to the oval major axis and move it downwards by introducing the side of the lid without the pressure relief valve.



2. Introduce the lid completely and align it with the oval neck.



3. Close the lid and fix it in the container by lowering the lever.



## WASHING

1. Remove the lid according to the instructions to have access to the inside of the container. The oval handhole permits having access to the inner surfaces of the container introducing an arm. Use detergents and cloths allowed for being used with stainless steel without scratching it and capable of removing the rest of the product that was stored.

2. In order to wash the lid, remove the removable pieces (gasket, pressure relieve valve) and submerge them in a cleaning solution.

3. If possible, disassemble the spear with the appropriate tool and submerge their pieces as well. If not, connect a standard coupler to the spear and make the cleaning solution circulate into the spear.

4. Submerge the lid in the cleaning solution.

5. Rinse the container, the lid, the spear and all the removable pieces with clean water following the same methodology as with the detergents.

6. Assemble all the pieces and close the container according to the instructions.

